

C&K 700L User instructions

[\[Full Set\]](#) [\[Part set\]](#) [\[Unset\]](#) [\[Reset\]](#) [\[Omit\]](#) [\[Back to Index\]](#)

Full set the system

1. Enter [user code] Exit tone sounds
2. Press [#] To abort full set

Part set the system

1. Enter [user code]
2. Press [*]
3. Press [0] Exit tone sounds

Unset the system

1. Enter [user code] Entry tone stops.

Reset system after alarm condition

1. Enter [user code]
2. Press [#] System now reset.

Omit a zone

1. Enter [user code]
2. Press [*] Followed by the zone number you want to omit, the LED for that zone will flash.
3. Press [*] Followed by the next zone you want to omit. You cannot omit zone 1.

Change your own user code

1. Enter [user code]
2. press [*]
3. Press [9]
4. Press [1] LED's 1234 will light up.
5. Enter new [User code] Confirmation tone will sound.

Test the alarm sounders

1. Enter [user code]
2. Press [*]
3. Press [9] All LEDs will light up, internal speaker will sound, Bell will sound, then the strobe will flash.
4. Press [#] At any time to abort bell test.

Walk test the detection devices

1. Enter [user code]

2. Press [*]
3. Press [9]
4. Press [4] Walk test detectors as required -
sounder tone changes to indicate
detector active.
5. Press [#] At any time to abort walk test.

Setup user codes

1. Enter [user code]
2. Press [*]
3. Press [9]
4. Press [2] LED's 1234 will light up.
5. Enter new [User code] Confirmation tone will sound.
6. To delete code
7. Enter [user code]
8. Press [*]
9. Press [9]
10. Press [2] LED's 1234 will light up.
11. Enter [0000] Code now deleted, confirmation tone
will sound.

View the event log

1. Enter [user code]
2. Press [*]
3. Press [9]
4. Press [3] The log routine will start viewing Day1,
the keypad buzzer will sound during
SET condition, the first alarm is shown
by the relevant LED being lit
continually, subsequent alarms will
flash quickly, omitted zones will flash
slowly.
5. Press [#] Will change between set and unset
logs.
6. Press [1] For log event 1.
7. Press [2] For log event 2, you can view up to 9
log events.
8. Press [0] To view last alarm.

Keypad personal attack alarm

1. Press [*] and [#] And hold, alarm will sound.